

HOW TO USE LABELER



1. Remove label guide by turning to the right and place your roll of labels onto the spooler. Replace the guide by pressing inward and turning to the left.



2. Pull labels under the transparent pressure plate. Open the bottom gate, releasing the latch marked "OPEN" (do not force), and thread label edge along the bottom gate.



3. Close the bottom gate by returning the latch marked "OPEN" back into the locked position. The serrated edge is used to remove the excess label liner.



4. Labels are released as you squeeze the handle. As you squeeze, pull the applicator along in a fluid motion over the surface of the item being labeled.



Cleaning/Removing Stuck Labels

Unscrew 2 screws. Easily remove stuck label by solvent for strong adhesive.

Notice:

- It's unnecessary to make a slit or slot on backing paper for feeding of labels.
- Film with less than 50mm thickness is unacceptable
- Use only die-cut labels
- A cotton-swab moistened with ALCOHOL, is recommended to wipe adhesive from Mecha-Sensor

Hydro-Gardens

P.O. Box 25845

Colorado Springs, CO 80936-5845

888-693-0578

hgi@hydro-gardens.com

www.hydro-gardens.com